

变频器外形与安装尺寸图

External and Installation Dimensions of Inverter

Unit: mm

Model	W	W1	W2	H	H1	D	M	N
S3100L-4T5.5G	180	160	160	298	284	180	6.5	6.5
S3100L-4T7.5G								
S3100L-4T11G								
S3100L-4T15G								
S3100L-4T18.5G								

